

MiDAS 2.0

Version 2.2.1.2 Release Notes

General Description

This update is a general maintenance release. This update also includes support for the new DRS Lightning RDT+ line of cameras. See below for a detailed list of changes contained in this release.

Detailed Changes from Previous Versions

1. Fixed Active Area dialog crash when adjusting active area on rotated camera.
2. Improved error handling when exporting analysis results when Excel is not installed.
3. Added support for the new DRS Lightning RDT+ camera.
4. Fixed handling of input of dynamic range for Data Acquisition.
5. Improved handling of registry queries.
6. Improved internal handling of control initialization.
7. Added an additional menu item to rescan for cameras without restarting MiDAS.
8. Added support for greater variety in naming of JPEG and TIFF image sequences.
9. Added a "Check for Updates" feature to display latest available version.
10. Fixed handling of inverted bitmap files (negative height).
11. Fixed issue where no selectable frame rates are displayed with GPS/IRIG.
12. Fixed bug preventing startup of GPS/IRIG.

Installation Instructions

If you are installing MiDAS 2.0 for the first time, follow the instructions in your Users Guide. If you are upgrading a previous version of MiDAS, you should select "Repair" at the installation screen option.

Operating Systems

This version has been tested with Windows NT 4.0 with Service Packs 5, 6 or 6a, Windows 2000 with Service Packs 1 or 2, and Windows XP Professional Edition.

Hardware and Camera Compatibility

Check with the Xcitex web site for a list of camera and data acquisition hardware compatibility. Make sure that you are running the latest firmware upgrades on your cameras to enable all the high-end features.

How to get Technical Support

Technical support addresses, URLs and phone numbers are found in the Help--> About box within the software. Please have your key tag number, registration number and software version number available when calling.

Xcitex, Inc.
25 First Street
Suite 105
Cambridge, MA 02141 USA
617-225-0080
617-225-2529 (facsimile)
<http://www.xcitex.com/>