

# MiDAS OS

Version 1.0.1.8 -- Release Notes

## General Description

---

This version update includes new divisions of features among the various licensing options and incorporates changes for Windows 7 compatibility.

## Detailed Changes

---

1. Fixed possible issues with canceled save operations when saving from multiple cameras.
2. Fixed possible issues when removing smart-trigger region.
3. Made system more robust when closing multiple playback views rapidly.
4. Added new division of features among various licensing options.
5. Incorporated changes for greater Windows 7 compatibility.

## Installation Instructions

---

Run the installation executable and follow the on-screen instructions. This version introduces a new installation scheme that should be simpler than our previous installation scheme.

## Operating Systems

---

This version contains tested drivers for Windows XP Professional Edition. Some additional testing has been performed under Windows 7. MiDAS OS has not undergone thorough testing with Microsoft Windows Vista or Windows 7. We recommend using Windows XP Professional Edition.

## Hardware and Camera Compatibility

---

MiDAS OS supports the Troubleshooter line of cameras from Fastec Imaging running the following firmware:

- MX1 model cameras: release 274
- MX21 model cameras: release 308 or higher.

Contact Fastec Imaging for updates to your camera firmware. MiDAS OS only works with MX1 cameras and MX21 cameras with serial numbers 070857X or newer.

MiDAS OS now also supports InLine cameras, Sportscam cameras, and TroubleShooter LE cameras from Fastec Imaging and the MotionPro cameras from Redlake.

## **How to get Technical Support**

---

Technical support addresses, URLs and phone numbers are found in the Help--> About box within the MiDAS OS software. Please have your key serial number, registration number and software version number available when calling.